


**NOTES:**

1. ALLOW XT5 TO CURE A MINIMUM OF 1 HOUR BEFORE APPLYING XT5 TACK COAT.
2. BROADCAST AGGREGATE INTO XT5 TACK COAT IMMEDIATELY AND LET CURE FOR A MINIMUM OF 12 HOURS.
3. SWEEP OR VACUUM OFF EXCESS AGGREGATE AND DISPOSE OF PROPERLY. DO NOT REUSE AGGREGATE.
4. XT5 IS NOT RATED FOR LONG TERM UV EXPOSURE AND MUST BE PROTECTED WITH BACKFILL, CONCRETE, OR WITHIN AN ENCLOSED TANK.
5. FOR LONG TERM UV EXPOSURE, SEE XT1.

**DECK ASSEMBLY - VERTICAL TRANSITION WITH CONSTRUCTION JOINT - REINFORCED - ENCAPSULATED WALL (OPTION 2)**

	SYSTEM NAME	DRAWING NUMBER	<h1>XT5</h1>
	XT5	24.440.2.4.2	
	DRAFTER	DATE	
	RJT	10/13/2023	

AS A SUPPLIER OF FINISHED PRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1