

TEMPORARILY  
ANCHOR TO FORM

3"

E.SHIELD 110

MINIMUM  
1'

E.SHIELD 205B

E.BASE 316

E.SPRAY 100 MIL

G:\My Drive\Epro Master Folder\Drafting\Details\Underslab\E.Protect+3.141.3 UNDERSLAB RAKER PAD AT MAT SLAB CONSTRUCTION JOINT - STEP 1.dwg [Detail] November 09, 2021 - 10:50am

## UNDERSLAB RAKER PAD AT MAT SLAB CONSTRUCTION JOINT - STEP ONE



SYSTEM NAME

E.PROTECT+

DRAFTER

RJT

DRAWING NUMBER

3.141.3

DATE

11/09/2021



AS A SUPPLIER OF FINISHED RPRODUCTS ONLY, EPRO SERVICES, INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING OR DIMENSIONS. THE PROJECT TEAM MUST VERIFY ALL DIMENSIONS AND SUITABILITY OF DETAILS. THE PRODUCTS LISTED ARE TRADEMARKS OF EPRO SERVICES, INC.

NTS

PAGE 1 OF 1